




Do not plug multiple USB Cables together to connect the projector to the classroom computer.



Do not plug multiple USB Cables together to connect the projector to the classroom computer.



Use one 15 ft (4.6 m) (Max) USB Cable to connect the projector to the classroom computer.



Total distance from the classroom computer to the projector cannot exceed 100 ft (30.5 m)

